



USER'S MANUAL

Hammock Stand


THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

SET UP THE HAMMOCK



This hammock stand is designed for convenient installation. There is a proper gap between the pipe fittings, which will cause slight shaking. This is a normal phenomenon and does not affect its load-bearing and use functions.

Components

① Base	2pcs
② Crossbar	1pc
③ Stand Frame	2pcs
④ Hook , Washer & Wingnut	2pcs
⑤ Bolt	4pcs
⑥ Camping Carry Bag	1pc

WARNING:

1. Do not leave children unattended in the hammock.
2. This product cannot be used as a swing.
3. Always enter the middle of your hammock.
4. Do not sit near the base.
5. Please make sure all hooks and wingnuts are tight.
6. Max Capacity:4501bs

ASSEMBLY INSTRUCTIONS

1. Place all parts on the floor.
2. Connect the crossbar with the bases, screw the bolts tightly into place.
3. Connect the stand frame with the base, twist screws tightly.
4. Put the hook and washer in the appropriate hole to suit hammock size.
5. Screw the wingnuts to hold the hook.
6. Hang the hammock according to the size. It should have only a slight curve when first fitting the weight. Adjust the curve by tightening or loosening the thread.
7. Inspect the hammock and frame regularly for deterioration or damage. Do not use if worn or damaged.