

Stainless Steel Pet Water Fountains User's Guide



- Healthy
- Convenient
- New Fashion

Patented product, please do not imitate

01. Tips

- ①. When starting out with a water fountain, pets may be curious about new things. At first, allow pets to get used to the water fountain at their own pace, some pets may take a few days or more, while others may start using it right away
- ②. The water pump has a built-in intelligent indicator light, and the three states are convenient for observing the water level in the drinking fountain.
 - a) The blue light is always on to indicate the normal working mode;
 - b) When the blue light and the red light flash alternately and the water cannot be discharged normally, it means that the water level in the drinking fountain is too low and needs to be replenished in time;
 - c) The red light is always on, indicating that the interior is in a state of water shortage. Please add water in time to avoid dry burning.



Normal working mode, the blue light is always on.



When the water level in the drinking fountain is too low, the blue and red light flashes



When the water dispenser is short of water, the red light will indicate

- ③. If you are using "hard water", a small amount of white mineral deposits may start to form on or inside the pump, which will eventually interfere with the proper rotation of the impeller; to avoid replacing or damaging the pump, take the following precautions
 - a) Clean the pump more frequently
 - b) Use a diluted vinegar solution (20% white vinegar and 80% water) to clean the pump weekly
 - c) Use bottled water instead of tap water
- ④. Your pet may prefer to place the water fountains away from normal feedings. It can be placed elsewhere, such as another location in the kitchen, or in a toilet or utility room
- ⑤. Add ice cubes to the sink to get fresh cold running water in summer

02. Installation and Features



03. Product Components



Water Pump & USB cable X 1pc



Filter Sponge X 1pc



Connecting Pipe X 1pc
Cleaning brush X 1pc



Activated Carbon Filter X 1pc



Filter Shield X 1pc



Water Tray X 1pc



Sprinkler X 1pc



Pet Water Fountains Base X 1pc

04. Disassembly and Cleaning

Activated carbon filter, should be replaced weekly.

- ①. When the pet water fountain is used for multiple pets or the pet has a lot of saliva, the frequency of replacing the activated carbon filter should be increased.
- ②. When cleaning the pet water fountain, the filter element can be rinsed, never use soap to clean the filter element, as residual soap debris is difficult to remove.

Pet water fountains, weekly cleaning is recommended

- ①. Unplug the water fountain and disconnect the power.
- ②. Remove the sprinkler, water tray, activated carbon filter element, filter shield in turn, take out the connecting pipe, and empty the water in the water fountain
- ③. Lift the pump upright, this will require a little force until the suction cup disengages
- ④. Then press the plastic bouncing rubber plug in the outlet, the device will pop out. After letting go, pull the wire up and out, remember not to use force. (See Figures 1, 2, 3)
- ⑤. The plastic part inside the wire is not allowed to be disassembled by the user (see the red marked in Figure 4)
- ⑥. Remove any hair, debris or rough food that has accumulated around edges and corners and around cord openings.
- ⑦. Use clean water and soap to clean the plastic parts of the pet water fountain. You can also clean the water fountain in the dishwasher, but the water pump wire should not enter the dishwasher; if the equipment conditions permit, it is recommended that you lower the water temperature in the dishwasher.
- ⑧. If some places or corners cannot be cleaned in place, you can use a cotton swab or a small cleaning brush to clean it.



Reminder: Do not let the water fountain run idly. It is only suitable for indoor use.

05. Daily Maintenance of Water Pump

★: Cleaning the water pump is critical to the life of your pet water fountains and to maintaining water quality, it is recommended to clean the water pump every two weeks




①. Remove the water pump from the pet water fountains as explained in the "Water fountains removal and cleaning" section

②. After removing the pump, use your thumb and forefinger to gently pinch either end of the water inlet cover and pull out. This may require inserting a finger into the seam of the intake hood to pry it open. (See Figures 5, 6)



③. Then, you need to put your fingernail into the upper left corner of the water chamber cover, gently pry it, and pull it out to remove the water chamber cover (Picture 7)



④. After taking out the water chamber cover, you can also remove the impeller (white, 3-piece) The impeller is held in place by magnetism. To remove, you can stretch your fingers under the blade and pull it out (Picture 8)



⑤. After disassembling the pump, you can clean its parts with warm water and soap, using a cotton swab or a small cleaning brush, reach into the motor cavity and remove any deposits (see Figure 9). For improved disinfection and removal, use a diluted vinegar solution (20% white vinegar and 80% water) to clean the pump motor and make sure to rinse it thoroughly with clean water



⑥. The pump can be reassembled after cleaning the parts

- Reinstall the impeller
- Reinstall the water cavity cover
- Reinstall the water inlet cover and adjust the water inlet

06. Reassembly of the Water Fountains



The USB jack goes through the wire mouth



Through the bottom wire hole



The bouncing soft plug is aligned with the mouth of device



Press to make sure it doesn't shake



Put on the filter cotton



The bottom of the water pump suction cup is facing down



Make sure it is placed in correct direction in the suction cup slot



Plug in the connecting tube




Align the nozzle in the middle of the filter shield



Put activated carbon filter in turn



Put on the water tray



Tighten the sprinkler