







Umbrella Side Table



Read the instructions before use of this product.

Please keep this instruction manual for future reference.

PARTS & HARDWARE LIST



PART	FIGURE	DESCRIPTION	QTY
A		TABLE TOP	1
B		TABLE LEG	2
C		SIDE PANEL	2
D		BOTTOM PANEL	1
E		UMBRELLA BASE POLE	1
F		PLASTIC UMBRELLA RING	1
G		M0.24"*0.59"BOLT	8
H		M0.24"*0.79"BOLT	3
I		M0.24"*1.18"BOLT	8
J		WASHER	19
K		ALLEN WRENCH	1

ATTENTION:

Keep children away during assembly. This item contains small parts that can be swallowed by children. Children should always be under direct adult supervision while using this product. Do not discard any of the packaging until you have checked that you have all of the parts and fittings required. Carefully remove the contents from the package. If any parts are missing, do not attempt to use the product until they have been obtained. Make sure that each bolt needed for all steps matches the corresponding figure to ensure proper assembly.



STEP 1

Attach the umbrella base pole (E) to the bottom panel (D) by using bolts (H) and washers (J). Hand tighten only.





STEP 2

Attach a side panel (C) to the table leg (B) by using bolts (I) and washers (J). Hand tighten only.





STEP 3

Attach the table top (A) to the table legs (B) by using bolts (G) and washers (J). Hand tighten only.



STEP 4


Attach the bottom panel (D) and umbrella base pole (E) to table leg (B) and side panel (C) by using bolts (G) and washer (J). Hand tighten only.



STEP 5


Use the allen wrench (K) to tighten all bolts. Do not over tighten. Over tightening may strip bolts. Place the table on the upright position and put the plastic umbrella ring (F) on the umbrella hole.

F.



STEP 6

Now you have your new WICKER UMBRELLA SIDE TABLE.
WARNING: Umbrella may not withstand high winds. To avoid injury or damage, do not use in high wind conditions. Always retract umbrella when not in use.



Cleaning and Maintenance

Clean frame with mild soapy water, rinse thoroughly. Dry frame parts completely. Do not use bleach, acid, or other solvents on the fabric and metal parts.

We recommend the use of furniture covers to protect the umbrella side table when not in use.

Inspect and tighten all bolts on a regular basis to ensure proper performance and safety.

In order to prolong the life and beauty of your Umbrella Side Table, we recommend storing it in a dry and protective area during offseason periods.