

# ASSEMBLY MANUAL

\*Assemble according to the instruction or it may cause error.  
Please make sure it is fully completed before using.

**⚠ WARNING:**  
**CHOKING HAZARD-SMALL PARTS.**  
**NOT FOR CHILDREN UNDER 3 YEARS.**

**1**

B Door hinge  
A Door hinge

B Door hinge  
A Door hinge  
A Door hinge  
B Door hinge

**2**

(x4)  
Long screw x22  
Φ=4mm L=20mm

Handle x2

**3**

Back pillar (Left)  
Back pillar (Right)  
Front pillar (Left)  
Front pillar (Right)

(x4)  
Long screw x22 Φ=4mm L=20mm

Back pillar (Left) x1  
Front pillar (Left) x1  
Back pillar (Right) x1  
Front pillar (Right) x1  
Bottom panel x1

(x6)  
Screw for Hinge x6 Φ=4mm L= 8 mm

A  
A Doorhinge x3

B  
B Doorhinge x3

Front door (Left) x1  
Front door (Right) x1

**4**



Supporting panel x1

**5**


Cabinet shelf x1

Side panel (Left) x1  
Side panel (Right) x1  
Rear panel x2

6





Operating panel x1



Screw for Hinge x6  $\Phi=4\text{mm}$  L= 8mm

7





Cooking bench x1



Long screw x22  $\Phi=4\text{mm}$  L=20mm

8



Upper side panel (Left) x1

Upper side panel (Right) x1




Upper shelf x1




Long screw x22  $\Phi=4\text{mm}$  L=20mm



9



13



10



Upper rear panel x1



Hook x3




Hanger panel x1



Long screw x22  $\Phi=4\text{mm}$  L=20mm

11




Upper door x1




Upper display panel x1

12



Faucet x1



Top cover x1



Long screw x22  $\Phi=4\text{mm}$  L=20mm



Spatula x1



Turner x1



Kitchen knife x1



Pan x1



Stewpot x1