





Operation Instructions



Power Lift Chair

CORD AND POWER CONNECTIONS INSTRUCTIONS




1.#1 Connect plug A and plug B together.

2.#2 When the button is pressed to the off position, the Red Light on the Power button is not lit. When the button is in the ON position, the Red Light in the Power Button will lit and the unit will operate.


3.#3 Remote control in left side Pocket.

ASSEMBLY INSTRUCTIONS




PARTS LIST

A




x1

B



x2

C



x1

D




x1

E




x1

STEP 1



STEP 2




STEP 1


To install the armrests, align the female brackets in the armrests with the male brackets in the chair base, slide the armrest A / B down on the base.

STEP 2


To install the back, align the female brackets in the back with the male brackets in the chair base, slide the back down on the base. See #4 Push down on the top of the back to lock the back into position. You will hear a click from each side of the chair to ensure the back is locked in properly.

OPERATING INSTRUCTION





Press the UP button to make the sofa lifted.



Press the DOWN button to lift down and recline the sofa.

Warnings

- 1) Sit down in the chair gently. To avoid tipping over, do not throw yourself into the chair. Move the chair into the reclining position slowly, making sure that no children or pets are in close proximity. Do not allow children to play on or around the chair, particularly when it is in an open position.
- 2) Close the recliner completely before getting out of it.
- 3) Never sit on the footrest when it is open, even if it is a child.
- 4) To eliminate the risk of tipping over, do not sit on the arms or footrest of the chair.
- 5) This chair is designed to be used by 1 adult at a time.
- 6) Maximum weight capacity is 300LBS, Do not allow any person who over 300LBS to sit on the recliner.
- 7) Please forbid people with the following ailments from using this sofa: Those people with severe symptoms of heart disease, high blood pressure, cerebral thrombosis and others who are sensitive to heat or completely insensitive to heat, those with brittle bones or have issues with waist support pregnant women, children and others where it has been determined they are not suitable to use this product under the guidance of doctors.
- 8) To fully recline the sofa, ensure the sofa well, you need to put the sofa at least 40cm away from the wall or any other obstacle.
- 9) Product cannot touch water, fire, etc. Product can also not come in contact with sharp objects (knives, nails, etc.)

Maintenance Manual Instructions

- 1) To avoid dropping, you should carry the sofa carefully.
- 2) If you find dirt and or stains on the chair, spray the sofa with a sofa specific cleaner then use a sponge or cloth to wipe the dirt away. Do not use water, soapy water or cleaner with waxed wooden areas. Take care to wipe the sofa carefully and gently.
- 3) Do not put the sofa in an area with direct sunlight and do not put the sofa directly in front of an air conditioner, this will fade the upholstery and make it brittle.